

SIA-C

Self & Dual Powered Overcurrent & Earth Fault Protection Relay



SELF-POWERED
TECHNOLOGY

INSTALLATION & COMMISSIONING GUIDE

1.....	RECEPTION & INSTALLATION.....	3
1.1.	Relay unpacking	3
1.2.	Relay verification.....	3
1.3.	Powering the relay up	4
1.3.1.	Keypad & LCD	5
1.3.2.	Test menu	6
1.4.	Relay installation	6
1.5.	Relay rear part	7
1.6.	Connection diagrams.....	9
2.....	USER INTERFACE	10
2.1.	Relay front part	10
2.2.	Bistable magnetic indicators (flags)	11
2.3.	LED Indicators	11
2.4.	Front communication. RS232 or USB	12
2.5.	How to install SICOM Software	13
2.6.	Setting-up the session: Password and access levels	13
3.....	FUNCTIONAL DIAGRAM	14
4.....	SELECTION & ORDERING CODES	15
5.....	TECHNICAL SPECIFICATION	16
6.....	OPENING MECHANISM (DEPENDING ON MODEL)	22
7.....	PROGRAMMABLE LOGIC CONTROL.....	23
8.....	FLOWCHART	24
8.1.	Test menu.....	24
8.2.	Menus	26
8.2.1.	Measurements menu	26
8.2.2.	States menu	27
8.2.3.	Settings menu	27
8.2.4.	Events menu	30
8.2.5.	Demand menu.....	31
8.2.6.	Fault reports menu	31
9.....	COMMISSIONING.....	32
9.1.	Thermal resistance.....	32
9.2.	Self-powering.....	34
9.2.1.	Single phase minimum self-powering checking	34
9.2.2.	Three phase minimum self-powering checking	34
9.2.3.	Verification of Leds/Signalling Outputs/LCD in self-powering conditions	34
9.3.	Measurements	35
9.4.	Protection functions	35
9.4.1.	Protection functions testing	35
10....	SIAC PROTOCOL.....	38

1. RECEPTION & INSTALLATION

1.1. Relay unpacking

Previously to any handling action, confirm that relay carton box is in good conditions, no broken or damaged due to external manipulation or during storing or moving process. If packing is correct, proceed to unpack and you should find following element:

- SIAC Electronic protection relay.
- User Guide.
- Testing protocol.




Testing protocol is a certificate that relay has passed all factory testing process with correct results.

In case some fault is detected, consider putting into quarantine period the relay and contact Fanox for further instructions.

1.2. Relay verification

When relay is unpacked, please, take your time to confirm following checking list to be sure that everything is ok:

- Metallic case not damaged and well assembled. No loose screws due to transport or movement conditions




- LCD and front cover not damaged or scratched.



- Quality sticker and terminal sticker correctly stuck.



- Rear terminals in good state, being able to do a good wiring connection.



1.3. Powering the relay up

Model with RS232 (DB9 connector) port → KITCOM:

Thanks to the external battery KITCOM the powering and adjusting process of the relay is very easy and it allows the user to test the relay.

KITCOM with DB9 connector:



The power comes from two AA batteries (IEC LR06) of 1.5 Volts placed at the bottom of the kitcom. The equipment has a small Dc/Dc power supply that raises the voltage till the required 12 volts to operate the equipment and that is plugged into the front RS232 communications port (KITCOM).

Once the KITCOM is connected, the relay will be switched on and a led on the right of the relay (led battery) will blink indicating the relay is powered on through an external battery (KITCOM).

KITCOM with USB connector:



The relay is totally maintenance free. This is, there is no need of batteries to log events and fault reports and there is no need of batteries to maintain date and time.

NOTE: Date and time must be correctly set the first time the relay is operative, and energy must be kept at least "1 hour" to maintain the RTC for 72 hours once the energy is lost.

Besides, the possibility of using external battery power, together with the possibility of activating the trip contact from the test menu, allows the trip circuit to be tested before the transformation center is powered up. So, it is clear the KITCOM useful for cases like commissioning operations, discharges, and repairs to the transformation center.

Using battery power does not block the RS232 communications port, as it can be used simultaneously.



Once the relay is powered through the Kitcom, it is recommended to check:

Model with USB port:

Depending on model, a USB cable connected directly to the PC can be used to power the relay up. The USB cable is plugged into the front communications port. Using USB cable for power supply does not inhibit the USB communications port, as it can be used simultaneously. A power bank can be also connected to the front port to switch the relay on.

- Model → Directly, complete model on top line and phases/neutral current measurement on bottom line are displayed. Once “C” key is pressed the name of phase and neutral currents (instead the complete model) is displayed on the top of LCD Standby screen.



- Serial number (8 digits) and Firmware Version → HOLD ▲



1.3.1. Keypad & LCD

- Use the KEYPAD, ensure that all the push-buttons work correctly (no difficulties while pushing them, check out if the relay reacts by pushing each of the buttons).



- Use the KEYPAD to enter in the relay's menu and make sure that no text is lost while going from one menu to another.
- Follow the sequence: Left ◀, Down ▼, Right ▶, Up ▲, OK, C and RESET and the following screen should be displayed:

LOCAL Setting
1 19200-8-N-1

- If the contrast of the LCD is not the correct one, enter to “CONTRAST” menu by holding “◀” for 3 seconds. Then, change it by using up or down buttons to increase or decrease the contrast.



1.3.2. Test menu

NOTE: When performing test menu, protection won't be available and it will possible to open circuit breaker. Only authorized personnel can do this job.

Press ◀, ▼, ▶ sequentially and hold **OK**. The relay will ask for the password "5555" to enter to the test menu (or customer password if default "5555" has been modified).

It will be checked that the LEDs, Magnetic indicator flags and Outputs are activated if OK key is pressed and it will be deactivated if OK key is pressed again. LEDs, Magnetic indicators and outputs will be checked to verify the hardware is OK:




	Action	Checking
OK, OK	Led 1	Led 1 activated
▼, OK	Led 2	Led 2 activated
▼, OK	Led 3	Led 3 activated
▼, OK	Trip output	Trip output activated
▼, OK	Output 2	Output 2 activated (*)
▼, OK	Output 3	Output 3 activated (*)
▼, OK	Output 4	Output 4 activated (*)
▼, OK	Flag Trip	Flag Trip activated (*)
▼, OK	Flag 50/51	Flag 50/51activated (*)
▼, OK	Flag 50/51N	Flag 50/51N activated (*)
▼, OK	Flag External Trip	Flag External Trip activated (*)
C	Skip from test menu	

(*) Depending on model

1.4. Relay installation

To fix the relay to the switchgear, use default holes in front of relay with appropriate fixing system. Do not manipulate relay to fix it on the switchgear.



How to change the internal commissioning battery (DEPENDING ON MODEL)

1. Disconnect the relay. Switch the power supply off to avoid any dangerous situation.
2. Unscrew the 4 screws on the front of the relay to extract it from the switchgear and access to the rear side of the relay.
3. Unscrew the 2 screws to remove the cover from the battery compartment.
4. Remove the battery and replace it respecting polarity (+ facing up):

Battery characteristics:

- AA 3.6V lithium battery
- Model LS14500 from SAFT
- Do not use rechargeable batteries or other types of battery

5. Put on the battery cover and tighten the 2 screws.
6. Put the relay into the switchgear again and tighten the 4 screws on the front to fix the relay.


Warning: HAZARD OF EXPLOSION

- Do not recharge the battery.
- Do not short circuit the battery.
- Do not crush the battery.
- Do not disassemble the battery.
- Do not heat the battery above 100°C (212°F)
- Do not throw the battery into fire or water.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

1.5. Relay rear part

Depending on the model, the rear part will be different. Consider the wiring of the switchgear and connect relay properly:




A1	Phase A current input for Measurement & power supply
A2	Phase A current output for Measurement & power supply
A3	Phase B current input for Measurement & power supply
A4	Phase B current output for Measurement & power supply
A5	Phase C current input for Measurement & power supply
A6	Phase C current output for Measurement & power supply
A7	Neutral current input for Measurement & power supply
A8	Neutral current output for Measurement & power supply
D1	Auxiliary Voltage – (*)
D2	Auxiliary Voltage + (*)
D3-D4	External trip (*)
D5	Positive for the inputs (*)
D6	Digital input 1 (*)

D7	Digital input 2 (*)
D10	Digital output 1 NC (*)
D11	Digital 1 common output (*)
D12	Digital output 1 NA (*)
D13	Digital output 2 NC (*)
D14	Digital 2 common output (*)
D15	Digital output 2 NA (*)
D16	Trip output positive / ATC free potential output (*)
D17	Trip output gnd / ATC free potential output (*)
D18	RS485 – ground (*)
D19	RS485 - (*)
D20	RS485 + (*)
⊥	Earthing screw

(*) Optional depending on model.

Considering the mechanic “D”:




A1	Phase A current input for Measurement
A2	Phase A current output for Measurement
A3	Phase B current input for Measurement
A4	Phase B current output for Measurement
A5	Phase C current input for Measurement
A6	Phase C current output for Measurement
A7	Neutral current input for Measurement
A8	Neutral current output for Measurement
B1	Phase A current input for power supply
B2	Phase A current output for power supply
B3	Phase B current input for power supply
B4	Phase B current output for power supply
B5	Phase C current input for power supply
B6	Phase C current output for power supply
D1	Auxiliary Voltage – (*)
D2	Auxiliary Voltage + (*)

D3-D4	External trip (*)
D5	Positive for the inputs (*)
D6	Digital input 1 (*)
D7	Digital input 2 (*)
D10	Digital output 1 NC (*)
D11	Digital 1 common output (*)
D12	Digital output 1 NA (*)
D13	Digital output 2 NC (*)
D14	Digital 2 common output (*)
D15	Digital output 2 NA (*)
D16	Trip output positive / ATC free potential output (*)
D17	Trip output gnd / ATC free potential output (*)
D18	RS485 – ground (*)
D19	RS485 - (*)
D20	RS485 + (*)
⊥	Earthing screw

(*) Optional depending on model.


1.6. Connection diagrams

3 Phase CTs + Solid Neutral (Striker).




3 Phase CTs + Solid Neutral (Striker)

Mechanic D (Double rear terminals)






3 Phase CT + Solid neutral + TCM + Coil.




2. USER INTERFACE

2.1. Relay front part



Models with front USB available depending on the selection & ordering codes.



2.2. Bistable magnetic indicators (flags)


The front panel is equipped with 1, 2 or 3 bistable magnetic indicators (depending model list) which indicate the general trip or the specific cause of the last trip, respectively. The indicators remain in position even when the equipment loses power, so that the maintenance service can see the cause of the trip even through the equipment is not powered.

Once they have been activated, it is necessary to manually reset them by pressing the “RESET” button. The operation of the magnetic indicators can be checked from the test menu.

Model 3 bistables	Magnetic indicator “50/51” activated	A trip has been caused by phase instantaneous overcurrent or phase inverse time overcurrent
	Magnetic indicator “50/51N” activated	A trip has been caused by neutral instantaneous overcurrent or neutral inverse time overcurrent
	“External trip” magnetic indicator	A trip has been caused by the activation of the direct trip input
Model 3 bistables for withdrawable model	Magnetic indicator “O/C TRIP” activated	A trip has been caused by phase inverse time overcurrent
	Magnetic indicator “HS-O/C TRIP” activated	A trip has been caused by phase instantaneous time overcurrent
	Magnetic indicator “E/F&HS E/F TRIP”	A trip has been caused by neutral instantaneous overcurrent or neutral inverse time overcurrent
Model 1 bistable	Magnetic indicator “TRIP”	There is a general trip without indicating the reason.

Apart from this signaling, the LCD will show the text <<PICK-UP>> when any protection function is activated.

3 Bistable magnetic indicators Withdrawable model 1 Bistable magnetic indicator



Once they have been activated, it is necessary to manually reset them by pressing the “RESET” button. The operation of the magnetic indicators can be checked from the test menu.

2.3. LED Indicators

The SIA-C front panel has three configurable LEDs. Depending on the model, by default have different meaning.

More than one type of power can be used simultaneously, and more than one LED can be activated thus. The operation of the LED indicators can be checked from the test menu.

The user can change the configuration of the LEDs depending on its requirements and the labels for the LEDs can also be adapted.

2.4. Front communication. RS232 or USB

The front port is installed on the front of the device. The connector used is a DB-9 female – DCE or USB connector (depending on the model).


The relays with a front USB port can be connected to the laptop directly through a USB cable (this connection allows one to switch the relay on and communicate simultaneously).

For the models with an RS232 front port, the KITCOM can be connected to this communications port to supply the device with an external battery. It should be pointed out that this port can be used simultaneously for communication, even when an external battery is powering the device.

To communicate the relay with the PC or laptop, it is necessary to connect it through the front RS232 port.

To ensure the correct working of this connection, it is mandatory to consider the relay RS232 pinout, to make sure the used cable between the laptop/PC and the relay only uses the appropriate pins ensuring that the ones marked as “reserved”, that are for internal purpose, are not used.

1. The pinout of the front RS232 port (DB9 connector) is:



2. It is mandatory to ensure that the used cables to connect the relay to the laptop, use only the PINs designed for the communication, this is, PIN2, PIN3 and PIN5. The rest of the PINs are designed for Fanox internal purposes.
3. To connect the relay to the laptop, it is mandatory to follow the declaration in point #2. To facilitate the compliance of this point, the following options can be considered:
 - 3.1. Use the Fanox KITCOM. This external device will be connected to the SIA-C front port, and it will ensure the use of the necessary PINs to achieve the communication, while the relay is powered on without external supply.



- 3.2. If a commercial cable is used and the point #2 cannot be guaranteed, it is possible to cut the PIN9 of this cable to avoid any malfunctioning.



If this mandatory declarations are not followed, the correct working of the relay is not guaranteed.

2.5. How to install SICOM Software

To install the SICom it is necessary the following link:

<http://fanox.blob.core.windows.net/sicom/publish.htm>

The necessary drivers depending on the operative system can be downloaded from this page. The update of the software does not require any user's action, this is, if the computer is connected to Internet, SICom updates itself when it is started.

2.6. Setting-up the session: Password and access levels


Users must identify themselves with a password in order to start communications and to change the equipment settings or configuration using the HMI. Depending on the access level, it may or may not be possible to perform the operations shown on the table below.

ACCESS LEVEL	Read-only permission: Status and measurements Settings Configuration Events/DFR	Permission to: Change settings	Permission to: Delete Events Delete DFR	Permission to: Execute Commands	Permission to: Change Configuration Set Counters
2	YES	YES	YES	NO	NO
3	YES	NO	NO	YES	NO
4	YES	YES	YES	YES	NO
5	YES	YES	YES	YES	YES

Four passwords and associated access levels are set up when the equipment is configured using the SICom program. By default, the equipment is programmed with the following passwords and their associated levels:

PASSWORD	ACCESS LEVEL
2222	2
3333	3
4444	4
5555	5

3. FUNCTIONAL DIAGRAM



ANSI CODE PROTECTIONS

50	Instantaneous phase overcurrent
51	Inverse time phase overcurrent
50G	Instantaneous measured neutral overcurrent
51G	Inverse time measured neutral overcurrent
SHB	Second Harmonic Blocking
49T	External trip
46	Phase balance current protection
49	Thermal overload
CLP	Cold Load Pickup
46BC	Broken Conductor Detection
52	Breaker wear monitoring
79	AC Reclosing device
74CT	Phase CT supervision
74TCS	Trip voltage supervision
50BF	Circuit Breaker Failure
68	Zone selection interlocking
PGC	Programmable logic control

ADDITIONAL FUNCTIONS

CNT	Counters
RTC	Real Time Clock
PGC	Programmable Logic Control
HMI	Human Machine Interface
SER	Sequential Event Recording
DFR	Disturbance Fault Recording
LDP	Load Data Profiling
MET	Metering
STTG	Settings Groups
CMMD	Commands

4. SELECTION & ORDERING CODES

SIA-C

Overcurrent & Earth Fault Protection Relay – Dual & Self-powered

1 5											PHASE CURRENT MEASUREMENT 1 A 5 A
	1 5 A B										NEUTRAL CURRENT MEASUREMENT 1 A 5 A 0.1 A 0.2 A
		5 6									NET FREQUENCY 50 Hz 60 Hz
			0 1 3 4 5 A B D E F								POWER SUPPLY 0: Self powered 1: Self powered + 230 Vac (Dual) 3: Self powered + 24 Vdc (Dual) 4: Self powered + 48 Vdc (Dual) 5: Self powered + 100-230 Vac/dc (Dual) A: Self powered + Commissioning battery B: Self powered + 230 Vac (Dual) + Commissioning battery + front USB (Only for mechanics digits F and G) D: Self powered + 24 Vdc (Dual) + Commissioning battery + front USB (Only for mechanics digits F and G) E: Self powered + 48 Vdc (Dual) + Commissioning battery + front USB (Only for mechanics digits F and G) F: Self powered + 100-230 Vac/dc (Dual) + Commissioning battery + front USB (Only for mechanics digits F and G)
				0 1 2 3 4							ADDITIONAL FUNCTIONS Striker Striker with external trip (49T) Coil Coil with external trip (49T) Striker with external trip adapted at 230 Vac
					0 1 2						COMMUNICATIONS 0: Local port (Modbus RTU) 1: Local port (Modbus RTU) + RS485 (Modbus RTU) 2: Local port (Modbus RTU) + RS485 (Modbus RTU or IEC60870-5-103) ("Only for Adaptation C")
						0 1 2 3					INPUTS AND OUTPUTS Trip Trip + 2 outputs Trip + 2 outputs + 2 inputs Trip + 3 outputs
							1 2				MEMORY Non-volatile RAM memory Non-volatile RAM memory + Fast start-up
								A B C D			LANGUAGE English, Spanish and German English, Spanish and Turkish English, Spanish and French English, Spanish and Russian
									B C D E F G H I J		MECHANICS B: Horizontal assembly with 1 magnetic Flag C: Horizontal assembly with 3 magnetic Flags D: Double rear terminals, Vertical assembly with 1 magnetic Flag E: Vertical, Compact Size with 3 magnetic Flags F: Vertical, Compact Size with 3 Flags, Backlight LCD, Withdrawable G: Vertical Assembly, compact size with 1 magnetic indicator, Backlight LCD H: Double rear terminals, Vertical assembly with 1 magnetic Flag with anticorrosive treatment I: Vertical, Compact Size with 3 magnetic Flags with anticorrosive treatment J: Vertical, Compact Size with 3 magnetic Flags, Backlight LCD. SBEF application
										- A B C	ADAPTATION 50_1 + 51 + 50G_1 + 51G + 74TCS + PGC A: 50_1 + 51 + 50G_1 + 51G + 74TCS + PGC + 50_2 + 50G_2 + 3 Settings group B: 50_1 + 51 + 50G_1 + 51G + 74TCS + PGC + CLP + 4 Settings groups C: 50_1 + 51 + 50G_1 + 51G + 74TCS + PGC + 50_2 + 50G_2 + 46 + 50BF + 49 + 79 + 52 + 74CT + 46BC + SHB + 3 settings groups

5. TECHNICAL SPECIFICATION

Function 50-1 Function 50-2 (*)	Function Enable: Yes/No/SHB ^(*)
	Current Tap: 0.10 to 30.00 xIn (step 0.01 x In)
	Time Delay: 0.02 to 300.00 s (step 0.01 s)
	Activation level 100%
	Deactivation level 95%
	Instantaneous deactivation
	Timing accuracy: ± 30 ms or ± 0.5% (greater of both). Adaptation C with SHB permitted: ± 40 ms or ± 0.5% (greater of both).
Function 50G-1 Function 50G-2 (*)	Function Enable: Yes/No/SHB ^(*)
	Current Tap: 0.10 to 30.00 xIn (step 0.01 x In)
	Time Delay: 0.02 to 300.00 s (step 0.01 s)
	Activation level 100%
	Deactivation level 95%
	Instantaneous deactivation
	Timing accuracy: ± 30 ms or ± 0.5% (greater of both). Adaptation C With SHB permitted: ± 40 ms or ± 0.5% (greater of both).
Function 51	Function Enable: Yes/No/SHB ^(*)
	Curve Type: IEC 60255-151 and IEEE curves. IEC (Definite time, standard inverse, very inverse, extremely inverse, long time inverse) and IEEE (Moderately inverse, very inverse, extremely inverse).
	Time delay: 0.02 to 300.00 s (step 0.01 s)
	Time Dial (TMS): 0.02 to 1.25 (step 0.01)
	Current Tap: 0.10 to 7.00 xIn (step 0.01 xIn)
	Curve, current activation level: 110%
	Curve, current deactivation level: 100%
	Defined time, current activation level: 100%
	Defined time, current deactivation level: 95%
	Instantaneous deactivation
	Timing accuracy for IEC and IEEE curve selection: ± 30 ms or ± 5% (greater of both). Adaptation C With SHB permitted: ± 40 ms or ± 5% (greater of both).
	Timing accuracy for defined time selection: ± 30 ms or ± 0.5% (greater of both). Adaptation C with SHB permitted: ± 40 ms or ± 0.5% (greater of both).
Function 51G	Function Enable: Yes/No/SHB ^(*)
	Curve Type: IEC 60255-151 and IEEE curves. IEC (Definite time, standard inverse, very inverse, extremely inverse, long time inverse) and IEEE (Moderately inverse, very inverse, extremely inverse).
	Time delay: 0.02 to 300.00 s (step 0.01 s)
	Time Dial (TMS): 0.02 to 1.25 (step 0.01)
	Current Tap: 0.10 to 7.00 xIn (step 0.01 xIn)
	Curve, current activation level: 110%
	Curve, current deactivation level: 100%
	Defined time, current activation level: 100%
	Defined time, current deactivation level: 95%
	Instantaneous deactivation
	Timing accuracy for IEC and IEEE curve selection: ± 30 ms or ± 5% (greater of both).

	Adaptation C With SHB permitted: ± 40 ms or $\pm 5\%$ (greater of both). Timing accuracy for defined time selection: ± 30 ms or $\pm 0.5\%$ (greater of both). Adaptation C with SHB permitted: ± 40 ms or $\pm 0.5\%$ (greater of both).
Function SHB (*)	Function enable: No/Yes
	Current Tap: 10 to 50% (step 1%)
	Reset Time: 0.00 to 300.00 (step 0.01 s)
	Block Threshold: 0.10 to 30.00 xIn (step 0.01 xIn)
	Activation level: 100%
	Deactivation level: 95%
	Temporized deactivation
Function 49 (*)	Function enable: No/Yes
	Current tap: 0.10 to 2.40 In (step 0.01xIn)
	ζ heating: 3 to 600 min (step 1 min)
	ζ cooling: 1 to 6 x ζ heating (step 1)
	Alarm: 20 to 99% (step 1%)
	Trip level: 100%
	Deactivation level: 95% of alarm level
	Timing accuracy: $\pm 5\%$ respect of theoretical value.
Function TB (*)	Function Enable: Yes/No
	Tap: 1.50 to 20.00 xIn (step 0.01 xIn)
Function 46 (*)	Function enable: No/Yes
	Curve Type: IEC 60255-151 and IEEE curves.
	IEC (Definite time, standard inverse, very inverse, extremely inverse, long time inverse) and IEEE (Moderately inverse, very inverse, extremely inverse).
	Time delay: 0.02 to 300.00 s (step 0.01 s)
	Time Dial (TMS): 0.02 to 1.25 (step 0.01)
	Current tap: 0.10 to 7.00 xIn (step 0.01xIn)
	Curve, current activation level: 110%
	Curve, current deactivation level: 100%
	Defined time, current activation level: 100%
	Defined time, current deactivation level: 95%
	Instantaneous deactivation
	Timing accuracy for IEC and IEEE curve selection: ± 30 ms or $\pm 5\%$ (greater of both).
	Adaptation C With SHB permitted: ± 40 ms or $\pm 5\%$ (greater of both).
	Timing accuracy for defined time selection: ± 30 ms or $\pm 0.5\%$ (greater of both).
	Adaptation C With SHB permitted: ± 40 ms or $\pm 0.5\%$ (greater of both).
Function CLP (*)	Function Enable: Yes/No
	Settings groups: 1 to 4 (step 1)
	No load Time: 0.02 to 300.00 s (step 0.01 s)
	Cold load Time: 0.02 to 300.00 s (step 0.01 s)
	Open breaker activation 0.6% In and reset threshold: 0.8% In
Function 50BF (*)	Function Enable: Yes/No
	Time Delay: 0.02 to 1.00 s (step 0.01 s)
	Open breaker activation and reset threshold: 0.6% In
Function 74CT (*)	Function Enable: yes/no
	Time Delay: 0.02 to 300 s (step 0.01 s)
	Timing accuracy: ± 30 ms or $\pm 0.5\%$ (greater of both)
Function 74TCS	Trip supervision through the control of the trip voltage level.

Function 68 (*)	Available through configurable inputs and outputs thanks to the programmable logic (PGC).
Function 52 (*)	Maximum number of openings: 1 to 10.000 (step 1)
	Maximum accumulated amperes: 0 to 100.000 (M(A ²)) (step 1)
	Opening time: 0.02 to 30.00 s (step 0.01 s)
	Closing time: 0.02 to 30.00 s (step 0.01 s)
	Excessive repeated openings: 1 to 10.000 (step 1)
	Repetitive openings/Time: 1 to 300 min (step 1 min)
	Open breaker activation and reset threshold: 0.6% In
Function 79 (*)	Function Enable: Yes/No
	Hold Enable: Yes/No/No Time
	Number of reclosings: 1 to 5
	Reclosing time 1, 2, 3, 4, 5: 0.02 to 300 s (step 0.01 s)
	Hold time: 0.02 to 300 s (step 0.01 s)
	Reset time: 0.02 to 300 s (step 0.01 s)
	Safe time: 0.02 to 300 s (step 0.01 s)
Programmable control (PGC)	Logic
	OR4, OR4_LATCH, OR4_PULSES, OR4_TIMERUP, OR4_PULSE, NOR4, NOR4_TIMERUP, NOR4_PULSE, NOR4_PULSES, AND4, AND4_PULSES, AND4_TIMERUP, AND4_PULSE, AND4_LATCH, NAND4, NAND4_TIMERUP, NAND4_PULSE
Settings tables	Without adaptation: 1 Settings group. Adaptation A and C: 3 settings groups Adaptation B: 4 settings groups
	Selectable by input (*) or general setting.
SER	1024 events
Disturbance fault recording (DFR)	16 samples/cycle
	4 analog channels and 32 digital channels
	20 fault reports, 16 events in each. 10 disturbance records in COMTRADE format (50 cycles each). (*) Only for adaptation C
	COMTRADE IEEE C37.111-1991
Load Data Profiling (LDP)	Demand of power with the following characteristics: - Number of records: 168 - Recording mode circular - Sampling rate (interval): configurable through communications (1-60 min)
Trip output	For Striker: 24 Vdc-135 mJ For coil (optionally with TCM adapter): 250 Vac – 8A 30 Vdc – 8A
Outputs (*)	Up to 3 configurable outputs (output 2, output 3 and output 4): 220 Vdc – 1 A 250 Vac – 1 A
Inputs (*)	1 external trip input and 2 configurable inputs: They are activated by short-circuiting the terminals without external supply
Current measurements	RMS
	Fundamental values (DFT) (Only for adaptation C)
	Sampling: 16 samples/cycle
	±2% in a band of ± 20% the nominal current and ±4% or ± 5 mA in the rest of the band. Current measurement range: 0.1 to 30 times the nominal current
Communications	Local port (RS232 or USB depending on model): Modbus RTU

	RS485 port: Modbus RTU (*)
	RS485 port: Modbus RTU or IEC 60870-5-103 (*)
Self powering from current	Three phase self-powering level: Adaptation C: $I_n = 1A \rightarrow I > 0.13 \times I_n$ $I_n = 5A \rightarrow I > 0.1 \times I_n$ Other adaptations: $I > 0.1 \times I_n$
Power supply (*)	230 Vac ($\pm 20\%$)
	24 Vdc ($\pm 20\%$)
	48 Vdc ($\pm 20\%$)
	100-230 Vac/Vdc ($\pm 15\%$)
Battery Supply	Externally, with adapter (Kitcom) DB9 port (*)
	Internal commissioning battery (*)
Transformers	Power supply and measurement standard CTs /1 or /5
Environmental conditions	Operating temperature: -40 to 70°C
	Storage temperature: -40 to 80°C
	Relative humidity: 95%
Mechanical characteristics	Metallic box
	Panel mounted
	Height x Width: Compact Vertical model: 177 x 155 (mm) Standard Vertical model: 177 x 189 (mm) Horizontal model: 177.8 x 290.3 (mm)
	Depth:
	Model with RS232 port:
	Compact Vertical model: 147.1 mm
	Vertical withdrawable model: 153 mm
	Standard Vertical model: 145.8 mm
	Horizontal model: 100.75 mm
	Model with USB port:
	Compact Vertical model: 151.7 mm
	Vertical withdrawable model: 153.6 mm
	Weight: 3.5 kg
	IP-54 panel mounted
(*) Optional depending on model	

IEC60255-151 Curves

The SIA-C relay complies with the curves shown in standard IEC 60255-151:

- Inverse Curve
- Very Inverse Curve
- Extremely Inverse Curve
- Long time Inverse Curve

There is a general mathematical equation that defines the time in seconds as a function of the current:


$$t = \frac{A \times D}{V^P - Q} + B \times D + K$$

$$V = \frac{I}{I_{adjusted}}$$

Parameters	A	P	Q	B	K
Long time Inverse	120	1	1	0	0
Ext. Inverse	80	2	1	0	0
Very Inverse	13,5	1	1	0	0
Inverse	0,14	0,02	1	0	0

The curve can move from its axis using the D time selection device, which the user can adjust.

$I_{adjusted}$ is the initial operating current set by the user.



IEEE Curves

The IEEE curves follow the following mathematical equation:

$$t = (TD) \times \left[\left(\frac{A}{V^P - 1} \right) + B \right] \quad V = \frac{I}{I_{adjusted}}$$

And we have the following curves:


- Inverse Curve
- Very Inverse Curve
- Extremely Inverse Curve

Which relate to the parameters figuring in the following table:

Parameters	A	P	B
Ext. Inverse	28,2	2	0,1217
Very Inverse	19,61	2	0,491
Inverse	0,0515	0,02	0,114

The curve can move from its axis using the TD time selection device, which the user can adjust.

$I_{adjusted}$ is the initial operating current, set by the user.



6. OPENING MECHANISM (DEPENDING ON MODEL)

The trip voltage level is associated to a striker, so the type of trip is a polarized one. If the opening mechanism is a coil the trip is a free potential one. There are a lot of models of strikers in the market, with different trip energies, being for example 50 mJ (0,05W·s) and operation voltage of 6V, or 135 mJ (0,1W·s) and operation voltage of 24V.

The opening mechanism is activated by means of a striker. The activation of the trip generates a pulse train.

The **Trip Voltage Level** setting allows adjusting the trip voltage level required by the selected striker. The default value is 17 Vdc, although there are several options:

12 Vdc 17 Vdc 22 Vdc 24 Vdc

The equipment will allow the trip when it gets the selected trip voltage, so if a lower level than the required by the striker is adjusted, it may result on tripping without enough energy and not activating the striker.

On the other hand, if a higher level that the required by the striker is selected, the activation of the striker is guaranteed, however, the fault trip time during start-up may be increased. Fanox encourages selecting the correct value of this critical setting and offers its expertise at any doubt.

Striker

The striker is a bistable device with a simple action. The striker shaft is moved by a spring. The striker is activated by a polarized low-power electrical signal, supplied by the relay if a fault occurs. Resetting the shaft to its position is done manually. Resetting the striker has to be done in such a way as to guarantee that the opening mechanism is closed. This is normally done manually.



Due to the existing variety in the market, it is important to check the voltage, the impedance and the necessary energy for its activation.

7. PROGRAMMABLE LOGIC CONTROL

Physical outputs are the real outputs of the Device. SIA C has a trip output and depending on the model, up to three digital outputs (*Output 2, Output 3 and Output 4*) and up to two inputs. SIA C device has 3 configurable LEDS, which receive the same treatment as the physical outputs. All the outputs (Leds and physical outputs) are the result of a PROGRAMMABLE LOGIC CONTROL which can be configured from HMI or from SICom software.

For each output, there is a LOGICAL GATE. It can perform a logical operation up to 4 binary states to obtain other binary result. In V3 of the PLC the LOGICAL GATES and the default configuration is:

LOGICAL GATE	HMI SYMBOL
OR4	+
NOR4	τ
OR4_LACTH	c
AND4_LACTH	Φ
OR4_PULSES	J
AND4	&
NAND4	\$
AND4_PULSES	\$
OR4_TIMER_UP	O
NOR4_TIMER_UP	P
AND4_TIMER_UP	Q
NAND4_TIMER_UP	R
OR4_PULSE	o
NOR4_PULSE	p
AND4_PULSE	q
NAND4_PULSE	r
NOR4_PULSES	t

LEDs	LED 1
	LED 2
	LED 3
PHYSICAL OUTPUTS	TRIP OUTPUT (DO NOT CONFIGURE) (**)
	Output 2
	Output 3
	Output 4
LOGICAL SIGNALS	Block 50/51
	Block 50/51/N/G
	Settings Group 1
	Settings Group 2
	79 Start (*)
	79 Enable (*)
	79 Level Block (*)
	52a (*)
	52b (*)
	50BF Start (*)

(*) Only for Adaptation C

(**) **NOTE:** In spite of being possible to configure the trip output (in firmware version 3.22 or below through SICOM or HMI and the rest of the versions through HMI), the configuration must not be changed, as this output must adapt how it works to the associated trip mechanism.

To get the outputs to be operative it is required the following current:

Nominal current: 1 A

Without Adaptation & Adaptation A and B:

Single phase: $0.35 \times I_n = 0.35 \text{ A}$

3-phase: $0.17 \times I_n = 0.17 \text{ A}$

Adaptation C:

Single phase: $0.40 \times I_n = 0.40 \text{ A}$

3-phase: $0.17 \times I_n = 0.17 \text{ A}$

Nominal current: 5 A

Any Adaptation:

Single phase: $0.35 \times I_n = 1.75 \text{ A}$

3-phase: $0.17 \times I_n = 0.85 \text{ A}$

8. FLOWCHART


8.1. Test menu

From the main menu, press the keys “◀”, “▼”, and “▶” in sequence and then press and hold the “OK” key until the “Test menu” appears on the display. The test menu is accessed by pressing the “OK” key again, and the “▲” and “▼” keys can be used to navigate through the different menu items. Each item can be activated or deactivated by pressing “OK” on it (if the item is deactivated, it is activated by pressing OK; if the item is activated, it is deactivated by pressing “OK”). Press the “C” key to exit the test menu.



Once “Led 1” appears, pressing “OK” the led is activated and pressing “OK” again, it is deactivated.

To go through all options, press “▼”. To activate and deactivate the options follow the same steps as in case of Led 1.



(*) Optional Depending on model

Direct Access

Version

The equipment versions menu can be accessed from the standby mode screen by holding “▲” key.

Press the “C” key to return to the standby mode screen.



Date and time

Press the “▶” key from the standby mode screen to access to date and time menu

Press the “OK” key to access the date-time modification screen. Use the “▶” and “◀” keys to position the cursor over the digit that you want to change and assign a value to this digit using the “▲” and “▼” keys. Once the date-time has been entered, press “OK” to change the equipment date.


Press the “C” key to return to the standby mode screen.



Contrast

Hold “◀” key from standby menu to access to Contrast menu. Use the “▲” and “▼” keys to select the desired value.


Press the “C” key to return to the standby mode screen.



Communication parameters


Hold “▼” key from standby menu to access to communication parameters menu.

Press the “C” key to return to the standby mode screen.



(*) Remote communication depending on the model.

8.2. Menus



(*) Optional Depending on model

The information in SIAC relay is organized through the following menus:


- Measurements
- Status
- Settings
- Events
- Demand
- Fault Report

From standby screen press “OK” key to access to the first menu “MEASUREMENTS” and press “▼” key to overview the rest of the menus in the relay

To return to standby screen, press “C” key.

It is also possible to access to Fault reports by pressing “◀” key.

8.2.1. Measurements menu



(*) Optional Depending on model

From the standby mode screen, press the “OK” key to access the first line of menus.


Use the “▲” and “▼” keys to position the cursor over the “MEASUREMENTS” screen and press “OK”.

Use the “▲” and “▼” keys to position the cursor over the measurement and to see its value.

Press the “C” key to return to the standby mode screen.

If “OK” key is pressed in any of the current measurements, the current is displayed in secondary instead of in primary.

8.2.2. States menu



States menu indicates the stuses of the relay (activated or deactivated) at real time.

From the standby mode screen, press the “OK” key to access the first line of menus.

Use the “▲” and “▼” keys to position the cursor over the “STATES” screen and press “OK”. This takes you to the status groups’ line.

Move the cursor over a group of statuses and press the “OK” key to access the statuses that belong to this group. Use the “▲” and “▼” keys to browse through the different statuses.

The information shows whether each status is active. The message “>Activated” appears under the name of the group in the status group menus if any of the statuses in that group are active.

Press the “C” key to return to the standby mode screen.


8.2.3. Settings menu

From the standby mode screen, press the “OK” key to access the first line of menus.

Use the “▲” and “▼” keys to position the cursor over the “SETTINGS” screen and press “OK”. This takes you to the settings groups’ line.

Use the “▲” and “▼” keys to position the cursor over a settings group and press the “OK” key to access the settings that belong to this group.

Use the “▲” and “▼” keys to move through the different settings. The information that appears underneath the setting name is its value.



50 protection function

The parameters to adjust are:


- **Function Enable:** The function is available to trip only if the permission is "YES". While this permission is "NO" the function will never BE ACTIVATED AND THE RELAY WILL NOT TRIP.
- **Current Tap:** It is the threshold. Once it is exceeded the function picks-up.
- **Time Delay:** If the function is picked-up during the adjusted value the relay will trip

Pressing "OK" key from the standby screen MEASUREMENT menu is displayed.

Use "▼" key till SETTINGS menu appears. Press "OK" to access to the different functions.

Use "▼" key to choose the wanted option (Permission, Tap or Time delay) and press "OK" to access to its settings parameters.

After inserting the password 5555 it will be possible to adjust the wanted value.



51P protection function

The parameters to adjust are:


- **Permission:** The function is available to work only if the permission is "YES". While this permission is "NO" the function will never be activated, and the relay will not trip.
- **Curve type:** It will be possible to choose between IEC Inverse, IEC Very inverse, IEC Extremely Inverse and Definite time
- **Time Dial:** This parameter moves the previous curves along the "Y" axis.
- **Tap:** It is the threshold. Once it is exceeded the function picks-up.
- **Time Delay:** This parameter has only sense if in "Curve type" it is selected Definite time option. If the function is picked-up during this adjusted value, the relay will trip

Pressing "OK" key from the standby screen MEASUREMENT menu is displayed.


Use "▼" key till SETTINGS menu appears. Press "OK" to access to the different functions.

Use "▼" key to choose the wanted option (permission, curve type, time dial, tap or time delay) and press "OK" to access to its settings parameters.

After inserting the password 5555 it will be possible to adjust the wanted value.



General settings



From the standby mode screen, press the “OK” key to access the first line of menus.

Use the “▲” and “▼” keys to position the cursor over the “SETTINGS” screen.

Press the “◀” key to access the general settings from the "SETTINGS" screen.

It is possible to change any setting from HMI or SICOM software except the setting “Serial Number2 that can be only read.


How to set CT Phase ratio

Pressing “OK” key from the standby screen MEASUREMENT menu is displayed.

Use “▼” key till SETTINGS menu appears. Pressing “◀” key it is accessed to GENERAL settings.

Use “▼” key to overview the options and press “OK” when “CT phase ratio” option appears.

After inserting the password 5555 it will be possible to adjust the wanted value.




How to set Trip Voltage level

Pressing “OK” key from the standby screen MEASUREMENT menu is displayed.

Use “▼” key till SETTINGS menu appears. Pressing “◀” key it is accessed to GENERAL settings.

Use “▼” key to overview the options and press “OK” when “Trip Voltage level” option appears.

After inserting the password 5555 it will be possible to select the desired value.



8.2.4. Events menu

From the standby mode screen, press the “OK” key to access the first line of menus. Use the “▲” and “▼” keys to position the cursor over the “EVENTS” screen and the number of events in the buffer will be displayed. Press “OK” and use the “▲” and “▼” keys to position the cursor over the events.

The “J” and “┘” symbols show if the event has been caused by the activation or the deactivation.

Each event contains the following information:


- Date-time
- Description of the event
- Size of the events buffer
- Position of the event within the list
- Caused by activation or reset
- Associated measurement

How to delete the events

Press “OK” key from the standby screen it is displayed MEASUREMENT menu.

Use “▼” key until EVENTS menu appears. Hold “RESET” key and insert the password 5555

After the erasing of the events it will be appear there is 1 event corresponding to “Events erased”



8.2.5. Demand menu

SIA-C relay provides the demand of current with the following characteristics:

- Number of records: 168
- Recording mode circular
- Sampling rate (interval): configurable through communications: 1 – 60 min
- Record format:
Date/Time; IMAX (in interval); IMAX (actual)
IA; IB; IC; IN

How to delete the demand

To delete the demand from the relay it is necessary to insert the password 5555 from the demand menu.



8.2.6. Fault reports menu

From the standby mode screen, press the “OK” key to access the first line of menus. Use the “▲” and “▼” keys to position the cursor over the “FAULT REPORT” screen. Press “OK” and use the “▲” and “▼” keys to position the cursor over the faults.

Once it is accessed to a fault report, press “OK”, to visualize the cause which has originated the fault report.

Pressing “OK” again it is accessed to the registered events that are related with that fault reports. The first event is the activation of the fault report. To visualize the rest events, use “▼” key.

How to delete the fault reports

To delete the fault reports from the relay it is necessary to insert the password 5555 from the fault report menu.



9. COMMISSIONING

9.1. Thermal resistance








The relay can support, with 3-phase balanced injection, the following values according to International Standards:

3xIn continuously



20xIn for 10 seconds

70xIn for 1 second

In the following table the different injection modes are described:

CURRENT GENERATION	INJECTION MODE	INJECTION SYSTEM	RELAY CONNECTION REAR	RELAY WITHSTAND ENERGY WAVEFORM
Single phase	Phase-Neutral	NOT APPLY	P-N: 	
	Phase-Phase		P-P: 	
Three phases	Phase-Neutral	Balanced (120°) Un balanced (0°)	P-N Balanced: 	
			P-N Unbalanced: 	

Considering this description, the real thermal image that will support the relay depending on the injection mode and injection system is shown below:

WAVE FORM	INJECTION MODE	THERMAL RESISTANCE
	SINGLE PHASE P-N	3xIn continuously 20xIn for 10 seconds 70xIn for 1 second
	3-PHASE BALANCED	3xIn continuously 20xIn for 10 seconds 70xIn for 1 second
	3-PHASE UNBALANCED	1xIn continuously 6.5xIn for 10 seconds 23 xIn for 1 second

NOTE: It is checked that thermal resistance values are re-defined not to exceed the declared value in the International Standard.

Commissioning recommendation:


- It is recommended to use Kitcom accessory for relay protection functions settings. Connect it for setting and disconnect it for testing purpose.
- Adjust manually current generation value without injecting current to relay, for not stressing it during adjustment process.
- Be sure that relay output contact is connected to generator tripping input in order to stop the generator, hence the current injection, after reaching adjusted tripping time. This way, relay will only withstand rated injected current during adjusted time at protection function settings, not maintaining current injection constantly, which could become a damaging situation for relay, as in other case, the internally handle energy will be higher than rated one.
- Not to perform repetitive trips continuously as the stress of the relay will be increased drastically, especially when high current is being injected on the relay.

By following these recommendations, relay should pass commissioning test successfully. If commissioning test is performed not following these recommendations, manufacturer won't be responsible for relay failure.

9.2. Self-powering


9.2.1. Single phase minimum self-powering checking

Adjust the current generator with HOLD 0.2 amperes, and suddenly, inject it to the relay, as it would happen in real situation when circuit breaker is close, powering network line.




9.2.2. Three phase minimum self-powering checking

Adjust the current generator with HOLD 0.1 amperes, and suddenly, inject it to the relay, as it would happen in real situation when circuit breaker is close, powering network line.



9.2.3. Verification of Leds/Signalling Outputs/LCD in self-powering conditions

Adjust the current generator with HOLD 0.2 amperes, and suddenly, inject it to the relay, as it would happen in real situation when circuit breaker is close, powering network line. Once the relay is switched up, increase current injection until $0.35 \times I_n$ is reached. At this value, the Leds and LCD backlit should be switched on:



9.3. Measurements

The accuracy of the measurement is $\pm 2\%$ on a band of $\pm 20\%$ over the nominal current and $\pm 4\%$ over the rest of the measurement range.

Some examples are shown below:

- Current injected $\Rightarrow I=1\text{ A}$: $\rightarrow \pm 2\%$ accuracy is complied.
- Current injected $\Rightarrow I=2\text{ A}$ as this current value is 20% higher than the nominal current ($I_n= 1\text{ A}$) $\rightarrow 4\%$ accuracy is complied.

9.4. Protection functions

Current injection procedure:

Adjust the Sverker current generator with HOLD 0,2 amperes, and suddenly, inject it to the relay, as it would happen in real situation when circuit breaker is close, powering network line. From this value, increase the current to achieve the function pick-up and the function trip.

9.4.1. Protection functions testing


- 50 instantaneous phase overcurrent protection:

Settings:

- Function Enable: YES.
- Current Tap: $1 \times I_n$.
- Time delay: 2 (sec)

The following information will be checked:

- Pick-up at 100% of the tap (1 A)
- Trip output is activated
- Output 2 is activated
- Flag is activated




- 50N/G instantaneous neutral overcurrent protection:

Settings:

- Function Enable: YES.
- Current Tap: $1 \times I_n$.
- Time delay: 2 (sec)

The following information will be checked:

- Pick-up at 100% of the tap (1 A)
- Trip output is activated
- Output 3 is activated
- Flag is activated




- 51 Inverse time phase overcurrent protection:

TEST 1:

Settings:

- Function Enable: YES.
- Curve type: IEC Inverse.
- Time Dial (TMS): 0.05
- Current Tap: $0.5 \times I_n$.
- Theoretical tripping time = 3.67 seconds (Fault current 0.55 A)




The following information will be checked:

- Pick-up at 110% of the tap (0.55 A)
- Trip output is activated
- Output 2 is activated
- Flag is activated

TEST 2

Settings:

- Function Enable: YES.
- Curve type: IEC Inverse.
- Time Dial (TMS): 1
- Current Tap: $0.5 \times I_n$.
- Theoretical tripping time = 4.98 seconds (fault current 2 A)




The following information will be checked:

- Trip output is activated
- Output 2 is activated
- Flag is activated

TEST 3

Settings:

- Function Enable: YES.
- Curve Type: IEC Inverse.
- Time Dial (TMS): 1
- Current Tap: $0.5 \times I_n$.
- Theoretical tripping time = 2.97seconds (Fault current 5 A)



The following information will be checked:

- Trip output is activated
- Output 2 is activated
- Flag is activated


- 51N/G Inverse time neutral overcurrent protection:

Settings:

- Function enable: YES.
- Curve type: IEC Inverse.
- Time Dial (TMS): 0.05
- Current Tap: $0.3 \times I_n$.
- Theoretical tripping time = 3.67 seconds (Fault current 0.33 A)

The following information will be checked:

- Pick-up at 110% of the tap (0.33 A)
- Trip output is activated
- Output 3 is activated
- Flag is activated




TEST 2

Settings:

- Function Enable: YES.
- Curve type: IEC Inverse.
- Time Dial (TMS): 1
- Current Tap: $0.3 \times I_n$.
- Theoretical tripping time = 5.75 seconds (fault current 1 A)

The following information will be checked:

- Trip output is activated
- Output 3 is activated
- Flag is activated




TEST 3

Settings:

- Function Enable: YES.
- Curve type: IEC Inverse.
- Time Dial (TMS): 1
- Current Tap: $0.3 \times I_n$.
- Theoretical tripping time = 2.97 seconds (Fault current 2 A)

The following information will be checked:

- Trip output is activated
- Output 3 is activated
- Flag is activated



Note: In TEST 2 and TEST 3 for 51 and 51N, fault current will be injected the directly to check the theoretical tripping time. Consider this time is calculated through an equation and this time depends on the injected current, so doing a ramp is possible but the theoretical tripping time will not be checked.

10. SIAC PROTOCOL

Model:						
Serial Number:						
Model and Versions:		Reading LCD model: Version:				
Test menu	☐ OK ☐ NOK					
Wiring checking	☐ OK ☐ NOK					
Signalling and Keypad	Led 1	☐ OK	Led 2 ☐ OK Led 3 ☐ OK			
	FLAG1	☐ OK ☐ N/A	FLAG2 ☐ OK ☐ N/A FLAG3 ☐ OK ☐ N/A			
	Trip Output	☐ OK ☐ NOK				
	Output 2	☐ OK ☐ N/A				
	Output 3	☐ OK ☐ N/A				
	Output 4	☐ OK ☐ N/A				
	Keypad	☐ OK ☐ NOK				
Self-power 3P (SIAC>0.1In)	Phase A ☐ OK	Phase B ☐ OK	Phase C ☐ OK			
Communications	☐ OK ☐ NOK					
Settings and configuration	☐ OK ☐ NOK					
Current measurements	☐ OK ☐ NOK					
Protection Functions	50-1 phase A:	☐ OK	50-1 phase B:	☐ OK	50-1 Phase C:	☐ OK
	50-2 phase A:	☐ OK ☐ N/A	50-2 phase B:	☐ OK ☐ N/A	50-2 phase C:	☐ OK ☐ N/A
	50G ☐ OK					
	50G-2 ☐ OK ☐ N/A					
	51 phase A:	☐ OK	51 phase B:	☐ OK	51 phase C:	☐ OK
	51G ☐ OK					
	49T ☐ OK ☐ N/A					
	CLP ☐ OK ☐ N/A					
	46 ☐ OK ☐ N/A					
	52 ☐ OK ☐ N/A					
	79 ☐ OK ☐ N/A					
	50BF ☐ OK ☐ N/A					
	74CT ☐ OK ☐ N/A					
	49 ☐ OK ☐ N/A					
	46BC ☐ OK ☐ N/A					
	SHB ☐ OK ☐ N/A					
	Data recording (Events, fault reports)	☐ OK				
	RTC	☐ OK				

NOTES:

**Bizkaia Technology Park**

Building, 604

Derio, 48160 Bizkaia - SPAIN

T. +34 94 471 14 09

fanox@fanox.com

www.fanox.com